

Snow Plow Blade

Item	Description	Qty
A	Blade	1
B	Skid Pads (pre-assembled)	2
C	Marker Tubes	2
D	Deflector	1
E	Top Plate (pre-assembled)	1

(52" Blade shown)



(kit contents continue on following pages)

Need help with your installation?



sales@superatv.com



www.superatv.com



1-855-743-3427



8:00am - 9:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday



Read instructions and view illustrations before beginning.


Thank You

For Choosing




(kit contents continued)

Blade Size	Hardware	Qty	
52"	 M10-1.50 x 35mm Lg. CHCS	 M10-1.50 Nylock Nut	6
60"			7
72"			8


Qty (4)  M8-1.25 x 25mm Lg. FHCS Qty (4)  M8-1.25 Nylock Nut

Top Plate (E) is pre-assembled to Blade (A).
Remove hardware and set items aside.




- Install Deflector (D) and Top Plate (E) to Blade (A) with hardware shown.

hardware quantities will vary depending on Blade length




- Install Marker Tubes (C). Marker Tubes (A) pass through Top Plate (E), Deflector (D), and Blade (A). Secure with hardware shown.



Adjust Skid Pads (B) after Blade, Mount, and Frame are installed to machine.

(A)

Pin must be installed as shown.



Use provided Spacers to achieve desired height.



Skid Pads may be style shown

Use Loctite after adjustments have been made.



(B)

Premature wear may occur if operating on asphalt or concrete.

Mounting hardware and Plow Springs included with Frame



SuperATV Frame, p/n SPF-P-F, shown.

SuperATV 52" Blade, p/n SPB-P-52, shown.



Mounting hardware and Plow Springs included with Frame

Notes:

- To reduce icing, allow Blade to reach same temperature as outdoors before beginning.
- Except for when pivoting Blade, always place Blade on ground before exiting vehicle.
- To Avoid damaging Blade, do not plow over pipes, roots, curbs, or other large objects.
- Treating Blade with automotive type paste wax will make snow easier to move off Blade.
- Inspect Blade for loose, worn, or damaged components before plowing. Correct any issues.
- Clean Blade after each use and before storing long term.
- Use touch up paint, or a light coat of oil or grease, on any bare metal.
- Lubricate all pivot points before each seasons use.
- Store Blade away from weather and in a dry area after each use.

Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warranted if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.