

INSTALLATION INSTRUCTIONS

Phantom Fully Adjustable Shocks

PRELOAD NUTS

- Cranking down will stiffen Springs and raise machine.

SPRINGS

- Contact SuperATV for different Spring options.

COMPRESSION ADJUSTOR

- Counter Clock Wise softens Shock.
- Clock Wise stiffens Shock.



Do not set Compression Adjustor to full clockwise position. Shock failure will occur.

NITROGEN FILL VALVE

- More gas results in stiffer compression.
 - Less gas results in softer compression.
- Do not use needle valve gauge (tire gauge).**
Schrader Valve tool must be used.

REBOUND ADJUSTOR

- Counter Clock Wise stiffens Shock (holds Shock down longer).
- Clock Wise softens Shock (holds Shock down shorter).

